

GRAPH INWALL TANK FACEPLATE PNEUMATIC

20189IN-P-* INSTALLATION INSTRUCTIONS









NOTE: Make sure the blue color pipe is connected



SPARE PARTS INSTALLATION/REPLACEMENT STEPS

1. For Removing

2. For Installation

a. Rotate Pneumatic assembly 20° anti-clockwise.





a. Place locating pin in locating slot. Locating pin **b.** Rotate Pneumatic assembly 20°
clockwise.



SERVICE PARTS



ocating slot

1339502 Pneumatic assembly 1278766-1 SS Self Tapping Screw 1339503 Button Position Panel

Kohler India Corporation Pvt. Ltd.



6th Floor, Office Tower, Ambience Island, NH-8, Gurgaon-122002, Haryana, INDIA. Customer Care : 1800 103 2244 (Toll Free) & +91-124-4319685 / 86 Email : indiacustomercare@kohler.com Website: www.kohler.co.in

All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging or availability at any time without notice.