


## Overview


- ❑ The K-410-K Falling Water wall-mount valve can be easily modified to work with water supplies coming from above the valve.
- ❑ There are two methods to modify the valve: reverse the valves inside the valve body, or rotate the indexers.
- ❑ For either method, the valve body will need to be installed upside down to accept the water supplies.

## Method 1: Reverse the Valves



- ❑ Use an adjustable wrench to remove the two valves from the valve body.
- ❑ Install the valves into the opposite ports and securely wrench tighten both valves.
- ❑ Complete the valve installation according to the valve installation instructions.

## Method 2: Rotate the Indexers



- ❑ Carefully remove the indexer clip from each valve.
- ❑ Rotate each indexer 90°. The indexer will only rotate in one direction.
- ❑ Reinstall the indexer clip into each valve.
- ❑ Complete the valve installation according to the valve installation instructions.