



**22540IN-4ND-\*\***  
WM SC LAV FAUCET

**ROUGH-IN DIMENSIONS (in mm)**



## PRESSURE & HOT INLET TEMPERATURE



P (BAR)





0.5 < 3 < 5.5




T (°C) <65

## TOOLS REQUIRED




## INSTALLATION INSTRUCTIONS


1




2




3



4




5




6


a.



b.



### AERATOR CLEANING AND SERVICING



Ensure there is no leakage from the sides of aerator after tightening.


### CLEANING INSTRUCTIONS



KOHLER CLEANING SOLUTION



## SERVICE PARTS



Finish	Bonnet
CP	1232081-CP
AF	1232081-AF
BN	1223041-BN

\*\*-Finish code must be specified when ordering.

THE BOLD LOOK  
OF **KOHLER**®

### Kohler India Corporation Pvt. Ltd.

6th Floor, Office Tower, Ambience Island,  
NH-8, Gurugram-122002, Haryana, INDIA.  
Customer Care : 1800 103 2244 (Toll Free) &  
+91-124-4319685 / 86

Email : [indiacustomer care@kohler.co.in](mailto:indiacustomer care@kohler.co.in)  
Website: [www.kohler.co.in](http://www.kohler.co.in)

All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging or availability at any time without notice.